




The HSEF interface hydraulically connects the elements of proportional valve HPV 77 with the elements of proportional valve HPV 41 when there is HFLS mid end section in HPV77 side.


The HSEF module must be inserted into the proportional valve configuration between the last HPV77 working section and the first HPV41 working section.

Up to 6 HPV77 working sections and 8 HPV41 working sections can be installed..

Description	Code
Cast iron HSEF interface	HSEF007705041



HSEF interface overall dimensions



HPV 77